

技术要求:

- 1、彩盒、纸卡：物料材质和尺寸要按文档要求，成品尺寸偏差2-3mm内的要求；
- 2、外箱：物料材质和尺寸要按文档要求，成品尺寸偏差正5mm内的要求；
- 3、珍珠棉：珍珠棉粘合处要平整、胶水要均匀、成品尺寸偏差2-3mm内的要求；
- 4、说明书，保修卡，标贴画册等印刷类包材，必须符合品质部验货要求；

*所有包材详细可对照:说明书检验作业指引: YWT-WI-PZ-15

印刷标贴件检验作业指导: YWT-WI-PZ-17

PVC标贴件检验作业指引: YWT-WI-PZ-21

①印刷内容、图案、文字字体应符合图纸或封样件要求，文字图案应清晰、饱满、无脱色及明显溢边；位置准确，水平偏斜不允许超过5mm，图案颜色深浅一致，油墨附着性好，用手指轻擦不脱色；

②包装材料须有防护措施，不允许因包装、运输等损坏其外表面；

③产品需符合欧盟Rohs指令规定的六种有害物质要求；

TECHNICAL REQUIREMENTS

1. Color box&paper card: material and size should be according to document requirements, the size of the finished product deviation within 2-3mm requirements;
2. Carton: material and size should be according to document requirements, the size of the finished product deviation within plus 5-10mm requirements;
3. PE foam: the bonding place of PE foam should be smooth, the glue should be even, the size of the finished product deviation within 2-3mm requirements;
4. Manual, warranty card, label, album and other printing materials must meet the inspection requirements of the quality department;

* Details of all packaging materials can be compared with: Inspection guide for incoming materials of packaging cartons - document No. : YWT-WI-PZ-15, YWT-WI-PZ-17, YWT-WI-PZ-21

① The printed contents, patterns and fonts shall meet the requirements of drawings or sealed samples, and the patterns shall be clear, full, no decolorization and obvious overflow edge; and the position shall be accurate, horizontal deflection is not allowed to exceed 5mm, pattern shall be consistent color, good ink adhesion, and not decolorizing with fingers;


② Packing materials must have protective measures and are not allowed to damage their outer surface due to packaging and transportation.

③ Products need to comply with the six hazardous substance requirements specified by the EU Rohs

					Model: X2		图号 Drawing No.	X2-SMS002
⑥	1	EC23040313 除湿量改为3L	何韵意	2023. 4. 28			版本 Version	B1
标记 Mark	次数 Frequency	文件号 File No	签名 Signature	日期 Date	处理工艺 Treatment process	折页式	物料名称 Material name	X2英文说明书
设计 Design	吴艳芬		标准化 Standardizatio	白复旦	尺寸 Size	75x130mm	材质 Material	100g双胶纸
审核 Audit	吴华培				表面处理 Treatment process		物料编码 Material coding	1100010611
工艺 Craft	黎志成		审批 Approve	罗天	克重 Weight		广东英为拓科技有限公司 GUANGDONG INVITOP TECHNOLOGY CO., LID.	
日期 Date	2023. 04. 28				比例 Proportion	1: 1		

ROTARY DEHUMIDIFIER

INSTRUCTION MANUAL



Model: X2

01/Important

Before using, please read this user manual carefully and keep it for future reference.

Warning

1. To avoid electric shock and fire, do not allow water, liquid or any flammable detergent to get into or to clean the product.
2. Do not spray insecticide, perfume or other flammable spray around the products.

Notice

1. When the power cord is damaged, it must be replaced by electrical technicians or professional personnel to avoid 2. danger.

Do not use when the plug, power cord or the product is 3. damaged

Do not block the air inlet and outlet, for example, do not 4. place objects on or in front of the air outlet.

Do not insert foreign matter into the product through the air 5. inlet.

This product should not be used by persons (including children) with physical disabilities, mental disabilities or lack of relevant experience and skills, unless they are given instructions by the person responsible for their safety. Do not allow children to play with the product or to clean and 6. maintain the product unsupervised.

If the power socket connected to the product is not in good contact, the plug of the product may become very hot.

7. Ensure that the power socket is in good contact.

8. Do not place any item above the product.

Ensure the product is used in condition of a stable and 9. horizontal surface.

Please leave at least 30cm of space on the back and sides of the product, and at least 50cm of space above the product when using.

10. Do not put the product directly under the air conditioner to prevent condensate dripping into the product.
11. Do not hit the product with hard objects (especially the air outlet and inlet).
12. Do not cover the air inlet with clothes, curtains and other articles.
13. Do not insert finger or other objects into the air outlet/inlet to prevent physical damage or trouble.
14. Do not use this product when using indoor aerosol repellent or in places filled with oil, flammable gas or chemical 15. fumes.


Please unplug the product before moving it. Do not move 16. the product by pulling the power cord.

17. Do not attempt to repair, disassemble or modify the product.

This product is limited to household use and under normal 18. operating conditions. It generally reaches a stable state after 30 to 60 minutes.

The room temperature will rise when product is used in a confined space.

02/Product overview



Thank you very much for using our products.

Please read the user manual carefully before use, and keep it for future reference.


03 /Specification

Model	X2
Dimension	254x157.5x394.7mm
Net weight	3.7kg
Rated input voltage	AC 220-240V 50/60Hz
Power	340W
Dehumidifying capacity	3L/D (30°C 80%RH)
Noise	High speed mode: 45dB Low speed mode: 30dB
Coverage area	0~50°C

04 /Instruction

Preparation:

When plug in, the screen will blink for 1S and then goes off,the machine enters the standby mode.



Power ON:

Press to switch the machine on or off, when turn off the machine , the fan will keep working for 90s. It is recommended not to unplug the machine during this period, otherwise insufficient heat dissipation will affect the life of the machine.

Timer button:

Press the timer button to set 4h and 8h timer or cancel.

Fan speed button:

When turned on the machine,it will run in high fan speed by default,press the button to change the mode between low fan speed and high fan speed.

Water full indicator:

When the water is full or no water tank is installed for more than 1 second, the water full indicator lights up to remind the user, and the machine enters the standby mode, when full of water alarm is ended and back to normal mode, it can restart to work.

Tilt protection:

If the machine tilts when operating, the machine will stop working, and the fan will continue running for 3 minutes, all buttons will be invalid, and it will enters the standby mode after back to normal mode.

The machine shuts down automatically after 24 hours of continuous operation.

05/Maintenance

Notice:

1. Ensure the device is unplugged before maintenance.
2. Do not immerse the air purifier into water or any liquid.
3. Do not use abrasive, corrosive or flammable cleansers (such as bleach or alcohol) to clean any part of the device.

Cleaning:

1. Turn off and unplug the appliance.
2. Wipe the outer cover of with neutral detergent and soft cotton cloth.
Note: When wiping the air outlet, ensure no water drop into the appliance.
3. Remove the tank, open the tank cover and flush the tank cover/tank with clean water.
4. Take out the filter, clean it with a vacuum cleaner or water, and dry it in a ventilated place. Do not put the filter in high temperature or under sunlight to dry out.
5. Recommended cleaning frequency of filter: once a month (cleaning frequency should be increased in air particulate matter or hairy environment).

Storage:

1. Turn off the device and unplug the power supply, after heater cools down , arrange and bundle the power cord.
2. Pour out the water in the tank and clean it.
3. Clean the air inlet/outlet, wipe the body with a neutral detergent and a soft cloth.
4. After the device is completely dried, put on a dust cover/bag and place it in a well-ventilated place and keep it away from direct sunlight .
5. If you do not use it for a long time, please turn on the device for a few minutes from time to time to ensure a good performance.

06/FAQ

Situations	Solutions
No working	<ul style="list-style-type: none">• Please check whether the plug is inserted into the power socket or the plug is loose.• Please check whether the power supply at home is normal.
Stop working suddenly	<ul style="list-style-type: none">• Please check whether the plug is loose.• Please check whether the power supply at home is normal• Please check whether there are objects in the inlet and outlet of the appliance. If there are blocked objects, the internal temperature of the appliance will be too high, which will activate the protection program and stop work.
Blinking power red light	Please contact the manufacturer for repair.